

Enter time:

101      :      1 = AM  
          :      2 = PM

Enter Digits, when done, press MENU

Fig. 1A  
(Prior Art)

Enter time:

00:00 AM

111 Use left and right Arrows to choose position  
Use up and down arrows to increment/decrement

Fig. 1B  
(Prior Art)

200




FIG. 2




Fig. 3A




Fig. 3B




Fig. 3C






Fig. 4



**Figure 5**



**Figure 6**